


Seydel Musikinstrumente - Innovation aus Tradition

Diese Mundharmonika wurde in mehr als 150-jähriger Tradition mit neuester Technologie im Haus **C. A. Seydel Söhne** gefertigt. Für Produkte die dennoch beim Kauf Fertigungsfehler aufweisen sollten, leisten wir **eine Garantie von zwei Jahren**. Bitte beachten Sie, dass die Stimmzungen des Instruments je nach Beanspruchung einer Materialermüdung unterliegen.


SPIELANLEITUNG

AKKORD




Die **Lippen leicht geöffnet** auf das Mundstück des Instrumentes aufsetzen. Beim Blasen (Ausatmen) oder Ziehen (Einatmen) erklingen zwei verschiedene Akkorde.

EINZELTON MIT LIPPING



Die **Lippen gespitzt** auf das Mundstück des Instrumentes aufsetzen. Beim Blasen (Ausatmen) oder Ziehen (Einatmen) erklingen zwei verschiedene Einzeltöne.

EINZELTON MIT ABDECKEN



Die **Lippen breit** auf das Mundstück des Instrumentes aufsetzen. Mit der Zunge zwei Kanäle abdecken. Beim Blasen (Ausatmen) oder Ziehen (Einatmen) erklingen zwei verschiedene Einzeltöne.

PFLEGEHINWEISE


1. Bringen Sie Ihre Mundharmonika vor dem Spielen auf Körpertemperatur, indem sie diese z. B. mit den Händen anwärmen.
2. Spülen Sie vor dem Spielen Ihren Mund mit Trinkwasser aus, damit keine Speisereste in die Mundharmonika gelangen können. Trinken Sie keine zucker- oder malzhaltigen Getränke vor dem Spielen.
3. Klopfen sie die Mundharmonika nach dem Spielen mit den Kanalöffnungen nach unten in Ihre Hand, um größere Mengen von Feuchtigkeit aus der Mundharmonika zu entfernen. Lassen Sie das Instrument ganz austrocknen.
4. Legen Sie das Instrument nicht in Wasser.
5. Zur Reinigung und Wartung kann das Instrument zerlegt werden. Reinigungsversuche mit Hilfe von Kompressoren, Gebläsen oder Staubsaugern zerstören die Stimmzungen.
6. C. A. Seydel Söhne bietet im Internet unter www.seydel1847.com ein einmaliges Wartungs- und Reparaturkonzept mitsamt dem passenden Werkzeug und allen Ersatzteilen an.

Seydel Musikinstrumente - Innovation aus Tradition

Diese Mundharmonika wurde in mehr als 150-jähriger Tradition mit neuester Technologie im Haus **C. A. Seydel Söhne** gefertigt. Für Produkte die dennoch beim Kauf Fertigungsfehler aufweisen sollten, leisten wir **eine Garantie von zwei Jahren**. Bitte beachten Sie, dass die Stimmzungen des Instruments je nach Beanspruchung einer Materialermüdung unterliegen.


SPIELANLEITUNG

AKKORD




Die **Lippen leicht geöffnet** auf das Mundstück des Instrumentes aufsetzen. Beim Blasen (Ausatmen) oder Ziehen (Einatmen) erklingen zwei verschiedene Akkorde.

EINZELTON MIT LIPPING



Die **Lippen gespitzt** auf das Mundstück des Instrumentes aufsetzen. Beim Blasen (Ausatmen) oder Ziehen (Einatmen) erklingen zwei verschiedene Einzeltöne.

EINZELTON MIT ABDECKEN



Die **Lippen breit** auf das Mundstück des Instrumentes aufsetzen. Mit der Zunge zwei Kanäle abdecken. Beim Blasen (Ausatmen) oder Ziehen (Einatmen) erklingen zwei verschiedene Einzeltöne.

PFLEGEHINWEISE


1. Bringen Sie Ihre Mundharmonika vor dem Spielen auf Körpertemperatur, indem sie diese z. B. mit den Händen anwärmen.
2. Spülen Sie vor dem Spielen Ihren Mund mit Trinkwasser aus, damit keine Speisereste in die Mundharmonika gelangen können. Trinken Sie keine zucker- oder malzhaltigen Getränke vor dem Spielen.
3. Klopfen sie die Mundharmonika nach dem Spielen mit den Kanalöffnungen nach unten in Ihre Hand, um größere Mengen von Feuchtigkeit aus der Mundharmonika zu entfernen. Lassen Sie das Instrument ganz austrocknen.
4. Legen Sie das Instrument nicht in Wasser.
5. Zur Reinigung und Wartung kann das Instrument zerlegt werden. Reinigungsversuche mit Hilfe von Kompressoren, Gebläsen oder Staubsaugern zerstören die Stimmzungen.
6. C. A. Seydel Söhne bietet im Internet unter www.seydel1847.com ein einmaliges Wartungs- und Reparaturkonzept mitsamt dem passenden Werkzeug und allen Ersatzteilen an.

Seydel Musical Instruments - Innovation Inspired By Tradition

C. A. Seydel Söhne has manufactured this harmonica in keeping with over 150 years of tradition, yet by using the most modern technology. However, in the case of manufacturing faults, we offer a **2 year guarantee** from date of purchase. Please be aware that the reeds of the instrument can be subject to general wear and tear depending on usage.


PLAYING INSTRUCTIONS

CHORDS




Place your **lips slightly** over the mouthpiece of your harmonica. When blowing (exhaling) and drawing (inhaling), you will hear two different chords.

SINGLE NOTE (PUCKERING)



Place your **lips puckered** over the mouthpiece of your harmonica. When blowing (exhaling) and drawing (inhaling), you will hear two different single notes.

SINGLE NOTE (TONGUE BLOCKING)



Place your **lips well over the top** and bottom plates of your harmonica, covering three holes. Block off two holes with your tongue so that only one is uncovered. When blowing (exhaling) or drawing (inhaling), you will hear two different single notes.

CARE INSTRUCTIONS

1. Before playing, warm your harmonica up to body temperature. This can be achieved by warming it in your hands.
2. Before playing, rinse your mouth with drinking water, so that no debris gets into the harmonica. Do not drink any sugary or malted drinks before playing.
3. After playing, tap the harmonica against your hand with the holes facing downwards. This will remove the majority of the moisture. Then let the instrument dry out completely.
4. Do not place the instrument in water.
5. The instrument can be dismantled for repair and maintenance. You will damage the reeds if you attempt to clean it with the aid of compressors, bellows or vacuum cleaners.
6. C.A.Seydel Söhne offers a unique repair and maintenance service along with all the associated tools and replacement parts at www.seydel1847.com



C.A. SEYDEL SÖHNE
HANDMADE IN KLINGENTHAL / GERMANY SINCE 1847


C. A. SEYDEL SÖHNE GmbH · Mundharmonikafabrik
Robert-Koch-Straße 1 · D-08248 Klingenthal
Telephone +49 (0) 374 67 225 48 · Telefax +49 (0) 374 67 224 53
info@seydel1847.com · www.seydel1847.com

Seydel Musical Instruments - Innovation Inspired By Tradition

C. A. Seydel Söhne has manufactured this harmonica in keeping with over 150 years of tradition, yet by using the most modern technology. However, in the case of manufacturing faults, we offer a **2 year guarantee** from date of purchase. Please be aware that the reeds of the instrument can be subject to general wear and tear depending on usage.


PLAYING INSTRUCTIONS

CHORDS




Place your **lips slightly** over the mouthpiece of your harmonica. When blowing (exhaling) and drawing (inhaling), you will hear two different chords.

SINGLE NOTE (PUCKERING)



Place your **lips puckered** over the mouthpiece of your harmonica. When blowing (exhaling) and drawing (inhaling), you will hear two different single notes.

SINGLE NOTE (TONGUE BLOCKING)



Place your **lips well over the top** and bottom plates of your harmonica, covering three holes. Block off two holes with your tongue so that only one is uncovered. When blowing (exhaling) or drawing (inhaling), you will hear two different single notes.

CARE INSTRUCTIONS

1. Before playing, warm your harmonica up to body temperature. This can be achieved by warming it in your hands.
2. Before playing, rinse your mouth with drinking water, so that no debris gets into the harmonica. Do not drink any sugary or malted drinks before playing.
3. After playing, tap the harmonica against your hand with the holes facing downwards. This will remove the majority of the moisture. Then let the instrument dry out completely.
4. Do not place the instrument in water.
5. The instrument can be dismantled for repair and maintenance. You will damage the reeds if you attempt to clean it with the aid of compressors, bellows or vacuum cleaners.
6. C.A.Seydel Söhne offers a unique repair and maintenance service along with all the associated tools and replacement parts at www.seydel1847.com



C.A. SEYDEL SÖHNE
HANDMADE IN KLINGENTHAL / GERMANY SINCE 1847

C. A. SEYDEL SÖHNE GmbH · Mundharmonikafabrik
Robert-Koch-Straße 1 · D-08248 Klingenthal
Telephone +49 (0) 374 67 225 48 · Telefax +49 (0) 374 67 224 53
info@seydel1847.com · www.seydel1847.com